

	4	3	2	1												
C-	C1	C2	C3	25 C4												
	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5
C-	C1	C2	C3	21 C4	C5	C6	C7	22 C8	C9	C10	C11	23 C12	C13	C14	C15	24 C16
	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21
C-	C1	C2	C3	17 C4	C5	C6	C7	18 C8	C9	C10	C11	19 C12	C13	C14	C15	20 C16
	52	51	50	49	48	47	46	45	44	43	42	41	40	39	38	37
C-	C1	C2	C3	13 C4	C5	C6	C7	14 C8	C9	C10	C11	15 C12	C13	C14	C15	16 C16
	68	67	66	65	64	63	62	61	60	59	58	57	56	55	54	53
C-	C1	C2	C3	9 C4	C5	C6	C7	10 C8	C9	C10	C11	11 C12	C13	C14	C15	12 C16
	84	83	82	81	80	79	78	77	76	75	74	73	72	71	70	69
C-	C1	C2	C3	5 C4	C5	C6	C7	6 C8	C9	C10	C11	7 C12	C13	C14	C15	8 C16
101	100	99	98	97	96	95	94	93	92	91	90	89	88	87	86	85
L				1				2				3				4
C-	C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12	C13	C14	C15	C16

WIRES 101-87 CABLE 1
WIRES 86-70 CABLE 2
WIRES 69-50 CABLE 3
WIRES 49-26 CABLE 4
WIRES 25-1 CABLE 5

Red numbers represent Battery Module numbers